



Nintendo Wii U Pro Controller Teardown

Travel into the Controller.

Written By: Frederic Morelli




Step 1 — Back panel.




- With the PH000 screwdriver get back the rear front.

Step 2 — Battery off.



- Get back the battery with a tool like a spudger.

 The battery is not stucked.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 06:58:08 PM.